

OpenWrt

Il seguente script bash consente di configurare Openwrt RC5 asterisk 1.2.7 PBX e Linksys WRT54GL 1.1 e deve essere inserito in /etc/init.d. Prima di procedere con la configurazione creare in /tmp/dir il vecchio file DNS.

```
#!/bin/sh
HOSTNAME=example.homepc.it
USERNAME=users
PASSWORD=password
TEMPDIR=/tmp
wget -O $TEMPDIR/dyndns.new.ip http://checkip.dyndns.org/index.html
if [ "`cat $TEMPDIR/dyndns.new.ip`" = "`cat $TEMPDIR/dyndns.old.ip`" ]
then echo "No new IP";
else wget -O $TEMPDIR/dyndns.upd.ip http://$USERNAME:$PASSWORD@streamer.net/nic/update?hostname=$HOSTNAME
echo "New IP";
cat $TEMPDIR/dyndns.upd.ip;
rm $TEMPDIR/dyndns.upd.ip;
fi
rm -f $TEMPDIR/dyndns.old.ip
mv $TEMPDIR/dyndns.new.ip $TEMPDIR/dyndns.old.ip
```